



# Specialty Power Windows<sup>®</sup>

## 1955 – 1957 Ford T-Bird

Installing power windows in 1955-1957 Ford Thunderbird involves removing door panels and manual regulators, installing new power regulator assemblies (marked RH/LH), and connecting wiring and switches.

### Key Installation Steps

- **Preparation:** Disconnect the battery and remove the door trim panels and existing manual window regulators.
- **Regulator Install:** Install the new power window regulator assemblies (RH and LH) into the door.
- **Wiring:** Install power window switches and wiring harness.
- **Power Supply:** Connect the voltage supply wire from the left-hand harness to power supply.
- **Grounding:** Ground the black wire from the harness to the kick panel area on both sides.
- **Completion:** Adjust the mechanism for proper operation.

### Important Tips

- **Adjustment:** Ensure the window tracks and vent window assemblies are correctly positioned before finalized, as adjustments are critical. Be sure all wires are out of the way of any mechanical components and regulator movement.

Specialty Power Windows  
6690 Jones Mill Court, Suite C  
Peachtree Corners, GA 30092

PHONE: (478) 994-9248  
TECH EMAIL: [tech@spwkits.com](mailto:tech@spwkits.com)  
SALES EMAIL: [sales@spwkits.com](mailto:sales@spwkits.com)  
CONTACT US: [contact@spwkits.com](mailto:contact@spwkits.com)

[www.specialtypowerwindows.com](http://www.specialtypowerwindows.com)

